


DP562 Setup Menu



User Functions
 Accessed by holding down the front panel "User" button for three seconds

- None
- Remote Control
- AES/EBU Channel Select
- LFE Output Mode
- Bitstream Detect
- Pink Noise