

Adjustment of viewing angle :

1. Hold down any key and turn unit on.
2. Press clear.
3. Press recall.
4. Press clear.
5. Press left hand blank key.
6. Press decay up.

Now adjust viewing angle by using hi-filt^{FOR} up and low-filt^{FOR} up. Switch terminal off and on, if display now reads "Connect RMX 16" do not complete next procedure. Should the display now read "Op Sys Ver 2.03" complete following procedure :

1. Press clear, press save.
2. Press enter, press save.
3. Press clear; press left hand blank.
4. Press decay up.
5. Press clear, press low-filt down.
6. Press decay down, press low-filt down.
7. Press decay down, press status.
8. Press clear, press status.
9. Press decay up.

Turn unit off then on, display should now read connect RMX 16.